

QUICK START

DT7 TREADMILL DESK

Begin Here

1. Position the treadmill under your desk



2. Attach the 9 Pin Data Cable
Connect to the desk's right base foot and push into the port on the back of the treadmill. Do not screw in.
3. Attach the Power Cord
Connect the power cord to the base of the treadmill then to a power outlet.
4. Turn the Power Switch on



4. Confirm that the Safety Key is securely in place
5. Press the Power button
6. Press and hold the Stop button for 1-3 seconds to reset the console
Stand on the siderails of treadmill.
7. Press Start
The treadmill belt will start to move. You can begin walking.
8. Adjust the speed with the up and down arrow buttons
9. Press Stop when you are finished

TROUBLESHOOTING

DT7 TREADMILL DESK




PROBLEM:

The console is erratic or not lighting up.

SOLUTION:

Check to make sure the treadmill desk is properly plugged in. Turn the power switch off and back on again and make sure the Safety Key is in place. Make sure the connectors located in the front of the treadmill and under the desktop are fully plugged in. If the problem persists contact LifeSpan Customer Service.




PROBLEM:

“UART” or “dc-6” appears in the display.

SOLUTION:

Turn the treadmill desk power switch off. Unplug the power cord. Disconnect the 9 pin data cable, then reconnect it. Make sure the thumb screws are properly tightened. Plug in the power cord. Turn the treadmill desk power back on and check to see if it functions properly.




PROBLEM:

The desktop surface is not level.

SOLUTION:

Check to make sure the base feet are on a level surface. Run calibration by pressing and holding the height adjustment buttons simultaneously for three seconds.



PROBLEM:

The treadmill motor seems strained or E1 comes up after several minutes of use.

SOLUTION:

This problem usually occurs when there is too much friction building between the treadmill belt and deck. The best thing to do is turn the treadmill off, lubricate the running belt with 100% silicone (non-aerosol), and turn the treadmill back on. Test the unit. If E1 still comes up after testing, contact LifeSpan Customer Service.

Please see Owner's Manual section Maintenance and Tips for more information.